



Ultrex SO

Ultrex SO is a concentrated, mildly acidic, non-sulfide containing liquid material formulated to produce an oxidized finish on a variety of base metals by simple immersion at room temperature. By varying the operating concentration of the Ultrex SO, a range of color tones, from brown to purple, to gray black, can be obtained. These colors may be obtained by immersion of the parts or by wiping the Ultrex SO onto the parts to be oxidized. The tone and adhesion of the Ultrex SO immersion deposit will also be influenced by the base metal being treated. The most uniform and adherent finishes will be produced on thoroughly clean solid brass, copper or silver. Plated parts can also be treated in the Ultrex SO solution provided the plated coating is of enough thickness. To obtain uniform finishes on plated parts, the plated deposit should be relatively uniform.

The surface finish produced by the Ultrex SO solution is extremely thin and can readily be obtained by tumbling, steel wool wiping, scratch brushing or mechanical polishing. Unique and interesting "antiqued" and "highlighted" finishes are produced in this matter.

Applications for the Ultrex SO solution include antiquing for Tiffany lamps, buttons, ornaments, hardware components, etc. Ultrex SO can also be used to produce antique pewter effects, for color coding of parts and as a final uniform finish. Since the Ultrex SO deposit is quite thin and has little corrosion resistance, parts treated with Ultrex SO should be lacquered for maximum service.

Operating Conditions

Concentration	1-part Ultrex SO:4 – 8 parts water
Temperature	75°F – 90°F
Immersion time	30 sec – 3 min depending on concentration and tone desired
Equipment	Plastic, fiberglass IX rubber-lined tanks
Control	Dip may be controlled by small additions (1 to 2 fluid ounces/Gal) of concentrated Ultrex SO. When the time interval to produce the desired tone becomes inordinately long and further additions of Ultrex SO do not



	increase rate of color production, the bath is spent and should be replaced.
--	------------------------------------------------------------------------------

Caution

If taken internally, Ultrex SO is poisonous. Antidote: induce vomiting; when vomit fluid is clear, give 2 tablespoons of Epsom salt or milk of magnesia in water. Get medical attention. Avoid contact with skin and eyes. Use protective clothing (rubber gloves) when handling this material. In case of contact with skin, affected area should be thoroughly flushed with water for at least 15 minutes and obtain medical attention.

Avoid contact of Ultrex SO with concentrated acids or oxidizing materials.

WARRANTY: HUBBARD-HALL INC. IS NOT RESPONSIBLE FOR THE MISUSE, MISAPPLICATION, OR MISHANDLING OF THIS PRODUCT. SEE THE TERMS AND CONDITIONS OF SALE ON OUR WEBSITE FOR ADDITIONAL TERMS AND CONDITIONS CONCERNING OUR PRODUCTS, INCLUDING BUT NOT LIMITED TO, LIMITATIONS AND DISCLAIMERS OF WARRANTIES AND LIABILITIES.

Our People. Your Problem Solvers.

For more information on this process,
please call us at 203.756.5521 or email: techservice@hubbardhall.com

Hubbard-Hall holds certifications for **ISO 9001:2015**, Responsible Distribution, as accredited by the **ACD** (Alliance for Chemical Distributors) and as a **Women-Owned Small Business**, as well as maintaining an association with **Omni-Chem**¹³⁶